

# 100W Moving Head User Manual

- 1、 Voltage: AC220V/50Hz
- 2、 Power: 150W
- 3、 LED: 100 W
- 4、 Working Model: DMX512, Master/Slave Auto SOUND
5. Dimming: 0~100%

## Menu

Menu	Introductions
Addr	A001---A512
CHnd	12CH
SLnd	Working Model
Pan	YES, NO MotorX
Tilt	YES, NO MotorY
SEne	(0-100)
LED	ON, OFF
DISP	YES, NO
TEMP	XXX
Ver	V100
Faet	YES, NO

Fine	Press Menu5S
Pan	0-127    -1-127    X
Tilt	0-127    -1-127    y
Color	0-127    -1-127
Gobo	0-127    -1-127

12Chs	Functions	DMX	Details
1	X	0-255	
2	X Fine	0-255	
3	Y	0-255	
4	Y Fine	0-255	
5	X Y Speed	0-255	Fast To Slow
6	Gobo	0-255	

7	Gobo Strobe	0	No		
		1-255	(1HZ~25HZ)		
8	Color Gobo	0--15	W		
		16--31	Color1		
		32--47	Color2		
		48--63	Color3		
		64--79	Color4		
		80--95	Color5		
		96--111	Color6		
		112--127	Color7		
		128-191	Auto Change1		
		192-255	Auto Change2		
		9	GOBO	0-7	W
8--15	Gobo1				
16-23	Gobo2				
24-31	Gobo3				
32-39	Gobo4				
40-47	Gobo5				
48-55	Gobo6				
56-63	Gobo7				
64-73	Gobo7 Shake				
74-82	Gobo6 Shake				
83-91	Gobo5 Shake				
92-100	Gobo4 Shake				
101-109	Gobo3 Shake				
110-118	Gobo2 Shake				
119-127	Gobo1 Shake				
128-191	Auto Change1				
192-255	Auto Change2				
10	Prism			0-7	Close
				8-127	opentheprism
		128-255	prismrotatesfromslowtofast		
11	MACRO	0-49	Chs1-10		
		50-200	Auto		
		201-255	Sound		
12	REST	0-240	no		
		241-255	5S		