

Downlights

SPARK Series


User Manual



Use Suggestion

- 1. Please read this manual carefully before installation and use it in the correct way.
- 2. This manual also contains the attached instructions.
- 3. Please keep this manual properly after reading and understanding it, so that the owner of this product can refer to it at any time.










Product category	Product name	Cut-out size	Form factor
COB anti-glare model	SE75L	Ф75mm	Ф82*H53mm
	SE88L	Ф88mm	Ф96*H58mm
	SE98L	Ф98mm	Ф106*H63mm
	SE113L	Ф113mm	Ф123*H68mm
Diffusion section	SE75D	Ф75mm	Ф82*H53mm
Diffusion section	SE88D	Ф88mm	—— Ф96*H58mm
Diffusion section	SE98D	Ф98mm	Ф106*H63mm
Diffusion section	SE113D	Ф113mm	Ф123*H68mm
Diffusion section	SE145D	Ф145mm	Ф155*H76mm
Diffusion section	SE170D	Ф170mm	Ф 185*H83mm
	Coroles		


Recessed spotlights

1. Narrow bezel shrapnel mounting









The above steps are limited to the installation of narrow frame lamps, and the specific appearance is subject to the actual product!





To secure safety, a qualified electrician is required to install/remove the luminaire.

The luminaire is used exclusivly for lighting and is to be installed/removed in accordance wiht Electricity regulations and installation instructions.