







ROBO KIDS 1-2 - Parts List

Parts List	Part Name / Code	Quantity
	Funny Card Pack 2 (PV0K-N011)	1
	DC Motor - 100 RPM (PM0D-N008)	1
	LED Block [Orange] (PC1D-N008)	1
	LED Block [Green] (PC1D-N009)	1
	Cross Axle - 45mm (PB0S-N004)	1
	Cross Connection Block (PB0S-N007)	2
	Cross Connection Axle (PB0S-N008)	4
	Motor Guide (PB0G-N001)	3
	Cross Hole Block (PB0S-N006)	4
	1 x 9 Bended Hole Block (PB0H-N006)	2
	1 x 7 Bended Hole Block (PB0H-N005)	2
	2 x 8 Flat Block (PB0F-N003)	2
	Wheel - Ø25 (PW0K-N001)	2
	Wheel - Ø50 (PW0K-N002)	1

	Wireless Remote Control (PC0C-N002)	1
	Remote Control Receiver (PC0R-N002)	1
	Sound Sensor (PC0S-N006)	1
	Connection Axle (PB0S-N001)	10
	1 x 10 Hole Block (PB0H-N004)	4
	1 x 6 Hole Block (PB0H-N003)	4
	1 x 4 Hole Block (PB0H-N002)	4
	1 x 2 Hole Block (PB0H-N001)	2
	2 x 8 Block (PB0N-N010)	11
	2 x 6 Block (PB0N-N009)	4
	2 x 4 Block (PB0N-N008)	4
	2 x 3 Block (PB0N-N007)	6
	1 x 12 Block (PB0N-N005)	13
	1 x 8 Block (PB0N-N004)	5
	1 x 6 Block (PB0N-N003)	5
	1 x 4 Block (PB0N-N002)	10

	1 x 2 Block (PB0N-N001)	5
	2 x 4 Flat Block (PB0F-N002)	3
	Main Block (PB0F-N001)	2
	IR Sensor (PC0S-N004)	2
	Cable 200mm (PL0M-N001)	1
	Tire - Ø50 (PW1N-N002)	1