

A4VG HYDRAULIC PARTS



16

| NO. | DESCRIPTION | PCS |
|------------|-----------------------|------------|
| 1 | CYLINDER BLOCK | 1 |
| 2 | PISTON SHOE | 9 |
| 3 | VALVE PLATE | 1 |
| 4 | RETAINER PLATE | 1 |
| 5 | BALL GUIDE | 1 |
| 6 | DRIVE SHAFT | 1 |
| 7 | SWASH PLATE | 1 |
| 8 | SADDLE BEARING & SEAT | 2 |
| 9 | BEARING | 2 |
| 10 | CHARGE PUMP | 1 |
| 11 | DISC SPRING | 4 |
| 12 | COIL SPRING | 1 |
| 13 | SPACER | 2 |
| 14 | SNAP RING | 1 |
| 15 | 7 PIN | 2 |
| 16 | SEAL KIT | 1 |