Mini LED Spider 8×10W RGBW



Maintenance

- 1. Please keep the light in dryness and avoiding use in wet place.
- 2. Using intermittently can be extended the life.
- 3. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
- 4. Please do not wipe the crust using organic menstruum for avoid to damaged the product.

Statement

The product has well capability and intact packing when leave factory, All of the user should comply with above warning item and manual , any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual. Please forgive that we will not be notice for technical change

Attention Item

- 1. For guarantee the life of product, please do not put it on the wet place and not use it the place over 40 degree.
- 2. Please don't lay the product on the un-fixable or shakable place.
- 3. Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.
- 4. Power supply should not be changed over +&-10% while the light is using, it will be decreased the life of lamp if the power is too high, but it will be influenced the luminosity if the power is too low.

- 5. After power off, if it is need used again, please cool down over 20 minuter.
- 6. Please look round the manual for ensure the product can be used normally.

DMX Channel Summary-7 Channels Mode

Channel	Value	Function
1.	0-255	Y1 Motor running
2.	0-255	Y2 Motor running
3.	0-255	Total dimmer, linear dimming-Dark to Bright
4.	0-255	Strobe, Slow to Fast
5.	0-234	Automatic function selection
	235-255	Sound control
6.	0-255	AUTO Mode Speed adjust
7.	241-255	Rest

DMX Channel Summary-15 Channels Mode


Channel	Value	Function	
1.	0-255	Y1 Motor running	
2.	0-255	Y2 Motor running	
3.	0-255	Total dimmer, linear dimming-Dark to Bright	
4.	0-255	Strobe, Slow to Fast	
5.	0-255	Red 1 overall dimming	
6.	0-255	Green 1 overall dimming	
7.	0-255	Blue 1 overall dimming	
8.	0-7 8-231	White 1 overall dimming	
	232-255	3	
9.	0-255	Red 2 overall dimming	
10.	0-255	Green 2 overall dimming	
11.	0-255	Blue 2 overall dimming	
12.	0-255	White 2 overall dimming	
13.	0-234	Automatic function selection	
	235-255	Sound control	
14.	0-255	AUTO Mode Speed adjust	
15.	0-255		

Display Control Instruction

Display Conti	rol Instruction	
Addr	8001-8512	512 Address Settings
Chnd	7C h	7 Channel settings
	15Ch	15 Channel settings
SLnd	n∄sŁ	Host self-propelled mode
	Soun	Host voice mode
	SL <i>R</i> u	Console mode
	1	
Shnd	Sh01-sh24	Effect 0 (recommended)
	spyd	Sp@1-sp@8
Soun	On oFF	Sound control mode
SoEn	0-99	Sound sensitivity regulatory
	T.	
ŁesŁ	yes	Self checking
disp	No-yes	Display flip
LEd	OFF	After 5 seconds off screen
	ON	Always on screen
Г		
٤iL1	no	Y1 motor is transferred
	YES	Y1 motor reversal
ŁiL2	no	Y2 motor is transferred
	YES	Y2 motor reversal
deFŁ	No-yes	w
	1	
dISP	no	Reverse Display
	YES	Display forward
	T	
RESŁ	YES	System Reset

Display Control Instruction

Welcome to use our light. The light uses energy-saving LED, long Product life, shockproof, dustproof, DMX receiver and self-running feature, which can produce a variety of vivid lighting effects, easy to operate, suitable for all types of entertainment decoration, architectural lighting industry.



Instructions: Press the function key A cycled out the eight different function effects, digital tube first two digits on behalf of which the current function (see menu). The last two digits represent the functions in which the address code or speed parameters. Press the B or C key to modify the parameter values. Press the D key to confirm.

Product Introduction

Power consumption:48W Fixing lamp:LED 8×6W RGBW

DMX-Control-channels:7/15 DMX Channels Shuttle:Flash rate:0--10HZ

Power Supply:AC90--275V,50--60HZ Dimmer:0-100% mechanic dimmer Long Lifespan LEDs(more than 60,000 hours)