



Maintenance

1. Please keep the light in dryness and avoiding use in wet place.
2. Using intermittently can be extended the life.
3. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
4. Please do not wipe the crust using organic menstruum for avoid to damaged the product.

Statement

The product has well capability and intact packing when leave factory, All of the user should comply with above warning item and manual, any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual.

Please forgive that we will not be notice for technical change

Attention Item

- For guarantee the life of product, please do not put it on the wet place and not use it the place over 40 degree.
- Please don't lay the product on the un-fixable or shakable place.
- Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.
- Power supply should not be changed over +&-10% while the light is using, it will be decreased the life of lamp if the power is too high, but it will be influenced the luminosity if the power is too low.
- After power off, if it is need used again, please cool down over 20 minuter.
- Please look round the manual for ensure the product can be used normally.

DMX Channel Summary-16 Channels Mode

Channels	function	explain
1.	0-255	X motor operation
2.	0-5	nothing
	6-127	Whether X motor is transferred
	128-255	X motor has no reverse
3.	0-255	Y1 motor operation
4.	0-255	Y2 motor operation
5.	0-255	Y3 motor operation
6.	0-255	Y1-3 X motor speed
7.	0-255	0-255 brightness adjustment
8.	9-249	Strobe
9.	1-7	Color Gradient effect
	8-255	Self walking effect (recommended)
10.	0-15	No effect
	16-44	Self walking effect 0 (recommended)
	45-74	Self walking effect 1
	75-104	Self walking Effect 2
	105-128	Self walking effect 3
	129-157	Voice effect 0 (recommended)
	158-187	Voice effect 1
	188-217	Voice effect 2
218-255	Voice effect 3	
11.	0-255	Speed / sound control sensitivity
12.	0-255	Red
13.	0-255	Green
14.	0-255	Blue
15.	0-255	White
16.	250-255	reset

DMX Channel Summary-48 Channels Mode

passageway	function	function
1.	0-255	X motor operation
2.	0-5	nothing
	6-127	Whether X motor is transferred
	128-255	X motor has no reverse
3.	0-255	Y1 motor operation
4.	0-255	Y2 motor operation

5.	0-255	Y3 motor operation
6.	0-255	Y1-3 X motor speed
7.	0-255	0-255 brightness adjustment
8.	9-249	Strobe
9.	1-7	Color Gradient effect
	8-255	Self walking effect (recommended)
10.	0-15	No effect
	16-44	Self walking effect 0 (recommended)
	45-74	Self walking effect 1
	75-104	Self walking Effect 2
	105-128	Self walking effect 3
	129-157	Voice effect 0 (recommended)
	158-187	Voice effect 1
	188-217	Voice effect 2
	218-255	Voice effect 3
11.	0-255	Speed / sound control sensitivity
12	0-255	Red 1
13	0-255	Green 1
14	0-255	Blue 1
15	0-255	White 1
16	0-255	Red 2
17	0-255	Green 2
18	0-255	Blue 2
19	0-255	White 2
...
...
48	250-255	reset

Display Control Instruction

Addr	001-512	512 address setting
------	---------	---------------------

CHnd	16CH	16 channel setup
	48CH	48 channel setup
SLnd	Auto	Automatic mode
	Soun	Audio Mode
	Slve 1	Console mode
	Slve 2	Auxiliary machine mode

SHnd	Show 0	Effect 0 (recommended)
	Show 1	Effect 1
	Show 2	Effect 2
	Show 3	Effect 3
SEnS	0-99	Sound sensitivity regulation
bLnd	Blac	No 512 signal zero
	Auto	No 512 signal from walk
	Sound	512 voice signal
	HoLd	No 512 signal to maintain the last control station (16 channel)
bRLR	RED	0-255 adjustment
	Green	0-255 adjustment
	Blue	0-255 adjustment
	White	0-255 adjustment
rPRn	OFF	X motor is turning
	ON	X motor reverse
rTiL	OFF	Y13 motor is turning
	ON	Y13 motor reverse
rEst	YES	System reset

Product Introduction

- ★ Power Supply:AC90--275V,50--60HZ
- ★ Power consumption:90W
- ★ Fixing lamp:LED 9×10W RGBW
- ★ DMX-Control-channels:7/15 DMX Channels
- ★ Shuttle:Flash rate:0--10HZ
- ★ Dimmer:0-100% mechanic dimmer
- ★ Long Lifespan LEDs(more than 60,000 hours)